







# AIR FACTORS

## STANDARD WEIR GATE

The Air Factors Double Nested Adjustable Air Weir Gate may be repositioned at any time after installation to change the direction of airflow or the length and size of the air pattern. The same assembly allows return air volume adjustment for further control of building air migration. Weir gates can also blank off selected sections of the diffuser.

More adjustability means a comfortable building environment. There is peace of mind in knowing that you have complete control of the air direction.



## TYPICAL ASSEMBLY

