

DESCRIPTIVE LINK INDEX

<u>Description</u>	<u>File</u>	<u>Models Shown</u>
1. INTRODUCTION		
Innovative Solutions	1-1A	B-20-EE
2. LINEAR AIR BAR		
Standard Weir Gate - Air Pattern Controller	2-A	B-20-EE, RAH-20-xx"
Exposed Flange	2-S-1A	B-xx-EE
Wide Flange	2-S-2A	B-xx-WFWF
Flush Flange	2-S-3A	B-xx-FF
Hidden Flange 5/8	2-S-4A	B-xx-HFHF
Hidden Flange 3/4	2-S-4B	B-xx-HFHF
Concealed Flange	2-S-5A	B-xx-CC
Perimeter Drywall	2-S-6A1	B-xx-HF-DW2
Perimeter Drywall Exposed Flange	2-S-6B1	B-xx-E-DW2
Stub / Exposed Flange	2-S-7A	B-xx-STUB-E
Stub / Flush Flange	2-S-7B	B-xx-STUB-F
Exposed / Flush Flange	2-S-8 A	B-xx-E-F
Flush / Wide Flange	2-S-8 B1	B-xx-F-WF
Concealed / Exposed Flange	2-S-9A	B-xx-C-E
Getty Flange-4	2-S-11A	B-xx-GF4
2-Slot Exposed Flange	2-D-1A	B-xx(2)-EE
2-Slot Wide Flange	2-D-2A	B-xx(2)-WFWF
2-Slot Hidden Flange 3/4	2-D-3B	B-xx(2)-HFHF
2-Slot Flush Flange	2-D-4A	B-xx(2)-FF
2-Slot Concealed Flange	2-D-5A	B-xx(2)-CC
3-Slot Exposed Flange	2-T-1	B-xx(3)-EE
3-Slot Wide Flange	2-T-2	B-xx(3)-WFWF
3-Slot Hidden Flange 3/4	2-T-3B	B-xx(3)-HFHF
3. LINEAR AIR BAR WITH JET PAIR		
Jet Pair - Air Pattern Controller	3-1	B-20-EE-JP
Exposed Flange	3-S-2	B-xx-EE-JP
Wide Flange	3-S-3	B-xx-WFWF-JP
Flush Flange	3-S-4A	B-xx-FF-JP
Hidden Flange 5/8	3-S-5A	B-xx-HFHF-JP
Hidden Flange 3/4	3-S-5B	B-xx-HFHF-JP
Concealed Flange	3-S-6A	B-xx-CC-JP
2-Slot Exposed Flange	3-D-1	B-xx(2)-EE-JP
2-Slot Wide Flange	3-D-2	B-xx(2)-WFWF-JP
2-Slot Hidden Flange 3/4	3-D-3B	B-xx(2)-HFHF-JP
2-Slot Flush Flange	3-D-4	B-xx(2)-FF-JP
3-Slot Exposed Flange	3-T-1	B-xx(3)-EE-JP
3-Slot Wide Flange	3-T-2	B-xx(3)-WFWF-JP
3-Slot Hidden Flange 5/8	3-T-3A	B-xx(3)-HFHF-JP
3-Slot Hidden Flange 3/4	3-T-3B	B-xx(3)-HFHF-JP
4. MODULAR AIR BAR		
Air Bar for Standard Grid	4-2C	B-15-EE, SAC-15-48"-8"Ø
Flat End Cap for Grid	6-2B	B-20-EE FLAT END CAP, B-20 STANDARD HANGER, B-20-EE

DESCRIPTIVE LINK INDEX

<u>Description</u>	<u>File</u>	<u>Models Shown</u>
5. PLENUMS AND RETURN AIR HOODS		
Supply Air Chamber (SAC)	5-1A	SAC-20-48"-10"Ø
Standard Dimensions	5-2A	SAC-xx-xx"-xx"Ø
2-Slot Standard Dimensions	5-3A	SAC-xx(2)-xx"-xx"Ø
Top Inlet	5-S-5B	SAC-xx-xx"-xx"Ø TOP INLET
Step Top Inlet	5-S-5C	SAC-xx-xx"-xx"Ø STEP TOP INLET
Return Air Hood (RAH) - Exposed Flange	5-R-1A	RAH-20-48"
Return Air Hood (RAH) - Hidden Flange	5-R-3	RAH-20-48"
6. ACCESSORIES		
Flanged End Caps	6-1A	B-20-EE FLANGED END CAP
Flat End Caps	6-2A1	B-20-HFHF FLAT END CAP
Mitered Ends - Exposed Flange	6-3A	B-20-WFWF WITH MITERED ENDS
Mitered Ends - Hidden Flange	6-3B	B-20-HFHF WITH MITERED ENDS
Mitered Corner - Hidden Flange	6-3D	B-20-HFHF 90° MITERED CORNER
Wall Mounting Bracket	6-7D-1	B-15 PERIMETER WALL BRACKET
Inlet Collar Damper	6-8A	SAC-20-48"-10"Ø WITH INLET COLLAR DAMPER
7. PERFORMANCE DATA		
Ceiling Plenum with Standard Weirs	7-1	All 1-Slot & 2-Slot Air Bar
Standard Weirs, 1" & 1-1/2" Slot with AF Plenum	7-2	B-10-xx, B-15-xx
Standard Weirs, 2" & 2-1/2" Slot with AF Plenum	7-3	B-20-xx, B-25-xx
Standard Weirs, 3" Slot with AF Plenum & Notes	7-4	B-30-xx
2-Slot, 1" & 1-1/2", Standard Weirs with AF Plenum	7-5	B-10(2)-xx, B-15(2)-xx
2-Slot, 2" & 2-1/2", Standard Weirs with AF Plenum	7-6	B-20(2)-xx, B-25(2)-xx
2-Slot, 3", Standard Weirs with AF Plenum & Notes	7-7	B-30(2)-xx
Ceiling Plenum with Jet Pair	7-8	All 1-Slot & 2-Slot Air Bar
Jet Pair, 1" & 1-1/2" Slot with AF Plenum	7-9	B-10-xx-JP, B-15-xx-JP
Jet Pair, 1-1/2" & 2" Slot with AF Plenum	7-10	B-15-xx-JP, B-20-xx-JP
Jet Pair, 2", 2-1/2" & 3" Slot with AF Plenum & Notes	7-11	B-20-xx-JP, B-25-xx-JP, B-30-xx,JP
2-Slot, 1" & 1-1/2", Jet Pair with AF Plenum	7-D-12	B-10(2)-xx-JP, B-15(2)-xx-JP
2-Slot, 1-1/2" & 2", Jet Pair with AF Plenum	7-D-13	B-15(2)-xx-JP, B-20(2)-xx-JP
2-Slot, 2", 2-1/2" & 3", Jet Pair with AF Plenum & Notes	7-D-14	B-20(2)-xx-JP, B-25(2)-xx-JP, B-30(2)-xx,JP
8. SUBMITTAL SHEETS		
Single Slot	8-1-A	All 1-Slot Air Bar & Plenums
Double Slot	8-1-B	All 2-Slot Air Bar & Plenums
Radial Curve - Exposed Flange with Flanged End Caps	8-3-A	B-20-EE
Radial Curve - Exposed Flange with Mitered Ends	8-4-A	B-20-EE
Concave Curve - Exposed Flange with Flanged End Caps	8-7-A	B-20-EE
9. INSTALLATION INSTRUCTIONS		
Exposed Flange Air Bar - Drywall Opening	9-S1-A	B-xx-EE
Wide Flange Air Bar - Framing Opening	9-S2-A	B-xx-WFWF
Hidden Flange Air Bar - Framing Opening	9-S3-A	B-xx-HFHF
Flush Flange Air Bar - Framing Opening	9-S4-A	B-xx-FF
2-Slot, Exposed Flange - Drywall Opening	9-D1-A	B-xx(2)-EE
2-Slot, Wide Flange - Framing Opening	9-D2-A	B-xx(2)-WFWF
2-Slot, Hidden Flange - Framing Opening	9-D3-A	B-xx(2)-HFHF
2-Slot, Flush Flange - Framing Opening	9-D4-A	B-xx(2)-FF

DESCRIPTIVE LINK INDEX

<u>Description</u>	<u>File</u>	<u>Models Shown</u>
Installation for Exposed Flange	9-S1-B	DRYWALL CLIP, B-20-EE, SAC-20-xx"-xx"Ø
Installation for Wide Flange (ATF)	9-S2-B	B-20 ATF TYPE-1 & -2 HANGERS, B-20-WFWF
Installation for Hidden Flange	9-S3-B	B-20 SAC END ATTACHMENT BRACKET
Installation for 2-Slot Hidden Flange	9-D3-B	B-20(2) SAC END ATTACHMENT BRACKET
Supply Air Chamber (SAC) on Radial Ceiling Curve Air Bar	9-E6-A	n/a
Field Cut Air Bar	9-E7-A	n/a
Perimeter Wall Bracket & Regulator	9-E8-A	B-10 PERIMETER WALL BRACKET REGULATOR, B-10-HF-DW2, SAC-10(DW2)-48"-8"Ø
Supply Air Chamber (SAC) Assembly with Spring Clips	9-S1-C	DRYWALL CLIP, SAC-20-xx"-xx"Ø, B-20-EE
SAC Assembly with ATF Type-2 Hangers	9-S2-C	B-20 ATF TYPE-2 HANGER
ATF (After The Fact) Hanger Hardware	9-S2-D	B-20 ATF TYPE-x HANGERS
Hemmed Edge Plenum & ATF Type-3 Hanger	9-S2-E	B-20 ATF TYPE-3 HANGER, SAC-20-xx"-8"Ø HEMMED EDGE, B-20-WFWF
Side-Wall Weir Support Bracket	9-S2-F	B-20 WEIR SUPPORT BRACKET, B-20-WFWF
10. SMOKE CURTAIN		
Exposed Flange	10-1	
Hidden Flange	10-2	
Smoke Evacuation	10-3	
Flat End Cap	10-4	
Mitered Corner	10-5	
Installation Options	10-6	
11. INDEX		
Descriptive Index	11-D-1	n/a